



## Chromebook touchpad tips

If you're using a Chromebook, use the touchpad to move the pointer and select items on the screen. Here are some gestures and actions supported by the touchpad:

**Move the pointer:** Simply move your finger across the touchpad.



**Click:** Just press down on the lower half of the touchpad. Since tap-to-click is enabled by default, you can quickly tap the touchpad to click.

**Right-click:** Click the touchpad with two fingers.



**Scroll:** Place two fingers on the touchpad and move them up and down to scroll vertically, left and right to scroll horizontally.



**Swipe:** Quickly move two fingers left or right to go backward or forward on web pages or while using apps.

**Drag and drop:** Click the item you want to move with one finger. With a second finger, move the item. Release both fingers to drop the item at its new location.

